

6 Ton Jack-Patty Instructions

Tools required: None

1. Remove the 4 bolts from the top of the unit.
2. Remove the pressing plate , removal jig, containment ring and piston
3. Use vegetable oil or "Pam" and place a thin coating on the inside of the containment ring and piston and place them back on the press stand.
4. Place the pollen atop the piston.
5. Cover the containment ring with standard tin-foil.
6. Place the pressing plate atop the tin-foil and refasten the bolts and washers hand tight on the 4 threaded rods. Be sure the pressing plate is flat against the top of the tin-foil and containment ring.
7. Use the hydraulic jack to press to desired hardness.
8. Remove the pressing plate.
9. Replace the pressing plate with the removal jig and continue pressing until your patty is exposed. Then peel it from the piston.
10. Be sure to clean the containment ring and piston with alcohol after each pressing.



Pressing Plate



Containment ring



Removal Jig



Piston